



Quick User Instructions for the Vertical SBX IP 320 system

Recording your mailbox greeting message

- Press **Change VM Recording** or press the **Callback** button
 - If you press the **Callback** button press 2 for User greeting
- The system will say “**If you want to leave a message press the # key**”
If you have already recorded a greeting the system will play your greeting
- If you're happy with your message hang up
- To **Rerecord** your message **press the # key** at any time
- Press the **HOLD/SAVE** key when done.

Accessing Voicemail

<p>From your phone</p> <ul style="list-style-type: none">• Press the Callback key. <p>At another phone:</p> <ul style="list-style-type: none">• Press The Callback key• press the # button• enter your extension number• enter your password and #	<p>Outside the office</p> <p>Call the office</p> <p>If someone answers have them transfer directly into your mailbox. While your greeting is playing, press the * key</p> <p>If the Auto Attendant answers Dial 9</p> <ul style="list-style-type: none">• enter your extension number• enter your password and #
---	---

You'll see on the display and hear a message telling you the number of messages

Use the **softkeys** for playing, deleting etc. Press the right arrow > navigation key to access additional options.

You can also **dial**:

1 Listen to messages

1 for new, 2 for Saved or 3 for urgent messages

While listening to a message dial:

- 1 = to listen to the current message again
- 2 = to listen to the next message
- 3 = to delete the current message
- 4 = to delete all received messages

2 Change mailbox greetings

- 1 Play greeting
- 2 Record a new greeting
- 3 delete greeting

3 Leave a message

Dial the extension number
Press **#** to start recording

to enter another mailbox

Transfer a Call Directly to a Voice mailbox

While on a call

- Press the **TRANS/PGM** Button
- Press the **CALLBACK** Button
- Press the **DSS**(Direct Station Selector) button **OR dial** the station number
- Hang up

To Change your voicemail password

- **TRANS/PGM** and **dial 32**
- Enter your new password
- Press **HOLD/SAVE**

Call Recording

- Press the **Call Recording** key any time **during a conversation**
- Press the **Call Record again** key to **stop recording** or hang up

Calls recorded are saved as voicemail messages.

Call Transfer

While on a call:

- Press the **DSS**(Direct Station Selector) button **OR dial** the station number.

The call is put on hold while transferring

- Wait for the extension to answer and talk **OR** hang up.
- If you talk prior to transferring, the call will ring on the extension when you hang up
- You can also press the outside line key again to retrieve the call

To use Paging

- Press the **Page All** button if programmed or **Dial 543**
- Hang up or wait for paged person if using Meet Me Paging

To use Meet Me Paging

When you've been paged, press the **Meet Me Page** button if programmed or **Dial 544**

To send a ringing call to voicemail press your DSS key

To retrieve a call that has just gone to your voicemail press the outside line key for that call.

Setting up the Programmable keys

To program a button as a speed dial:

- Press TRANS/PGM
- Press the desired flex key
- press the phone number soft key on the display
- Dial 9 plus the phone number
- Press Hold/Save when complete

To program a button for another station's mailbox:

NOTE: This button is used to show **Message Waiting status** and for **direct access** to another mailbox

- Press TRANS/PGM
- Press desired flex button
- Press TRANS/PGM 47 xxx - where 'xxx' represents the target mailbox number
- Press Hold/Save when complete

Other common Flex key functions

Consult user guide page 1-16 for more codes

Numbering plan is applicable to both 8- and 24-button models, except as noted.

Password Register TRANS/PGM + 31 Password Change TRANS/PGM + 32 Background Music TRANS/PGM + 73 Call Log TRANS/PGM + 57 Call Park 601-608 Camp-on TRANS/PGM + 85 Erase Page MSG TRANS/PGM + 67 Record User Greeting TRANS/PGM + 61 Erase User Greeting TRANS/PGM + 66 Record Page MSG TRANS/PGM + 65 Group Call Pick-up TRANS/PGM + 71 Headset Ring Mode TRANS/PGM + 76 Hunt Group 620-629 Handsfree/Tone/Private TRANS/PGM + 12	Redial TRANS + 97 Register Station Name TRANS/PGM + 74 Ring Answer Mode TRANS/PGM + 12 Ring Type TRANS/PGM + 11 Set Customer MSG TRANS/PGM + 52 Set Pre-selected MSG TRANS/PGM + 51 Set Wake-up Time TRANS/PGM + 41 Cancel Wake-up TRANS/PGM + 42 Speakerphone/Headset TRANS/PGM + 75 Two way recording TRANS/PGM + 54 Universal Night Answer 569 Speed Dial Direct Station Select 100-132 Station speed dial SPEED + 000-099 System speed dial SPEED +2000-2499
Outside Line Access Group 801-808 Group access 9 Individual Line Access 8801-8812 Listen Station Number TRANS/PGM + 63 Listen Station Status TRANS/PGM + 64 Listen Time & Date TRANS/PGM + 62 MPB Version Display TRANS/PGM + 72	Button Assignment unique to 7208D CALLBK TRANS + 92 CONF TRANS + 91 DND TRANS + 93 FLASH TRANS + 94 LOOP TRANS + 84 MUTE TRANS + 95 SPEAKER TRANS + 96

Attendant Functions Station 100 only

To set the ringing Mode

- press **FWD/DND**
- **Dial the MODE number**
1 Day, 2 Night, 3 On Demand, 4 Weekend, 5 Automatic mode switching, 6 Lunch
- Press **HOLD/SAVE**

To record Auto Attendant system greetings

- On station **100**:
- Press **TRANS/PGM** dial **06**
- the display should ask for a system number 001 to 100. **Dial** the greeting number
- Record a new greeting by pressing **#**
- Save the greeting by pressing the **hold/save** key.

Station Feature Cancel

The attendants can cancel features such as DND, Call Forward and pre-selected messages at other stations.

To disable active features at a station from the attendant station:

- Press the [TRANS/PGM] button.
- Dial 071.
- Dial the desired station range.
- Press the [HOLD/SAVE] button

System Time/Date Setting

The system must be in Programming mode. To enter programming mode

Press the [TRANS/PGM] button and dial *#. A confirmation tone will sound.

- Press the [TRANS/PGM] button.
- Dial 178.

To Change the time:

- Press Line 1. This is the top left Flex key
- enter 24 hour time
- Press the Hold Save button
- Lift and replace handset

To change the date

- Press the line 2 button. This is the second from top left Flex key
- enter the date in MMDDYY format (eg january 27, 2009=270109)
- Press the Hold Save button
- Lift and replace handset